

NS 5100 Error List

468 [David Lopez](#) Wed, Mar 21, 2012 [NS-5000/5100](#) 0 8014

AMANO.

Introduction

Maintenance

Errors

When an error is displayed, pull out the power cord plug. After the error display disappears, insert the power cord plug into the plug socket. In case a recovery cannot be made from the error status, contact your local AMANO dealer.

Error Table

Error No.	Cause	Corrective measure
01	When printing is started or terminated, the lift position sensor (upper part/lower part) cannot detect the position.	→ Pull out the power cord plug. After the error display disappears, insert the power cord plug into the plug socket.
02	When printing is started, the dot home position cannot be detected or it is impossible to quit from the dot home position.	→ Pull out the power cord plug. After the error display disappears, insert the power cord plug into the plug socket.
03	At the printing time, a dot timing pulse cannot be detected.	→ Pull out the power cord plug. After the error display disappears, insert the power cord plug into the plug socket.
04	At a print return operation, the dot home position cannot be detected.	→ Pull out the power cord plug. After the error display disappears, insert the power cord plug into the plug socket.
05	Program error	→ Pull out the power cord plug. After the error display disappears, insert the power cord plug into the plug socket.
Count End	Counter count-over error (Automatic print stop) The count method of the counter is set to "Subtraction" (dn) and the counter value is 000000.	→ Change the counter setting.

Online URL: <http://tkb.amano.com/article.php?id=468>