How to clear memory on PIX55, TCX45, OR PIX28

433 Frank Mateo Wed, Dec 7, 2011 Time Clocks 0 6609

AMANO

Introduction

How to clear memory on PIX55, TCX45, OR PIX28

1. Press / hold program button
2. Go to Other P5
3. Then dIAg 18
4. CLr d4
5. Choose 32 – clears memory

Conclusion

Thank you for your time, and have a great day. As always, feel free to submit ideas on topics you want addressed in the Amano Knowledge Base using the comments feature.

Amano Cincinnati, Inc. reserves the right to make equipment changes and improvements which may not be reflected in this article. Portions of this article may have been updated to include the latest hardware or firmware version, if applicable. Amano assumes no liability for errors and/or omissions. If you should find any errors or unclear information, please notify Amano by posting a comment.

Customer Support Information	Call toll-free in the U.S.: 800-253-9836 (outside U.S. call 973-364-0294) or Fax: 973-364-1091 Mailing address: Amano Cincinnati, Inc., 140 Harrison Ave., Roseland, New Jersey 07068 Web site: www.amano.com/time • E-mail: support@amano.com

Online URL: http://tkb.amano.com/article.php?id=433