

## If Hand Punch is rejecting too often or always shows "place hand" or "remove hand" in display

223 [Frank Mateo](#) Fri, Nov 11, 2011 [HandPunch](#) 0 5118

If the Hand Punch is rejecting too often or always shows "place hand" or "remove hand" in display

### Fix:

If the user space is greater than 0(password 3 via list users), then press the NO key 11 times to find the R C E values.

If hand punch has been cleaned (non-abrasive glass/window cleaner), R C E values must be between:

- R & C =  $-/+2$  (or -2 to 2)
- E =  $-/+20$  from 100 (or 80 to 120)

If the values are not within the above ranges, the clock must be submitted for repair. Please contact support for repair form and case #.

Phone 1-800-896-7035

Fax 1-973-226-7863

[tgsupport@amano.com](mailto:tgsupport@amano.com)

[ttsupport@amano.com](mailto:ttsupport@amano.com)

[www.amano.com/tkb](http://www.amano.com/tkb)

Online URL: <http://tkb.amano.com/article.php?id=223>