If Hand Punch is rejecting too often or always shows "place hand" or "remove hand" in display

223 Frank Mateo Fri, Nov 11, 2011 HandPunch 0 5282

If the Hand Punch is rejecting too often or always shows "place hand" or "remove hand" in display

Fix:

If the user space is greater than 0(password 3 via list users), then press the NO key 11 times to find the R C E values.

If hand punch has been cleaned (non-abrasive glass/window cleaner), R C E values must be between:

- R & C = -/+2 (or -2 to 2)
- E = -/+20 from 100 (or 80 to 120)

If the values are not within the above ranges, the clock must be submitted for repair. Please contact support for repair form and case #.

Phone 1-800-896-7035

Fax 1-973-226-7863

tgsupport@amano.com

ttsupport@amano.com

www.amano.com/tkb

Online URL: http://tkb.amano.com/article.php?id=223