MRX-35 ERROR 22

238 Alex Nieves Tue, Mar 15, 2011 FAQ's, How To's, Tricks, Tips   0 4544

HOW TO CLEAR ERROR 22 ON THE MRX-35?

ANSWER:

ERROR 22 MEANS MEMORY IS FULL. THERE ARE 50 CARDS ALREADY ON MEMORY. TO

CLEAR OUT THE ERROR YOU NEED TO CLEAR THE MEMORY OR WAIT FOR NEXT PAY PERIOD.

HERE ARE THE STEPS FOR THE CLEAR...

Online URL: