INITIALIZE NS-5100

HOW TO INITIALIZE THE NS-5100?

ANSWER:

1. REMOVE COVER AND HOLD DOWN **"+"** AND **"-"**

2. WHEN **"PASS0000"** APPEARS SET TO **1977** AND PRESS ENTER.

3. PRESS ENTER 2 MORE TIMES UNTIL **"1"** APPEARS.

4. CHANGE **"1"** TO **"7"** AND PRESS ENTER. WHEN **"00"**

5. APPEARS ON RIGHT SIDE OF DISPLAY CHANGE IT TO **"88"**.

6. PRESS ENTER. PRESS **"+"** TO CHANGE THE **7** TO LETTER **"C"**.

7. PRESS ENTER. REPROGRAM CLOCK.

Online URL: