

Print mechanism down and does not allow insertion of paper

373 [Frank Mateo](#) Wed, Sep 21, 2011 [PIX-55 Atomic Clock](#), [PIX-75 Atomic Clock](#) 8 46173

PIX-55 print mechanism down and does not allow insertion of paper

Fix:

If there is an error in the display, remove top cover with plastic key then remove back cover and press blue reset button in the back.

Online URL: <http://tkb.amano.com/article.php?id=373>