

Factory Reset PIX-55

396 [Frank Mateo](#) Wed, Dec 7, 2011 [Time Clocks](#) 1 17097

- Press **PROGRAM** for 2 seconds then release.
- Press **CHANGE** until "**Ot hr P5**" appears.
- Press **ENTER**
- Press **CHANGE** until "**diA9 18**" appears.
- Press **ENTER**
- Press **CHANGE** until "**clr d4**" appears.
- Press **ENTER**
- Press **CHANGE** until the right hand digit reads "**2**"
- Press **ENTER**
- Press **CHANGE** until the left hand digit reads "**3**"
- Press **ENTER 2 (two)** times.
- Press **PROGRAM** to exit.

Your Time Clock has now been reset to the factory default settings.

Online URL: <http://tkb.amano.com/article.php?id=396>