Error 1 in CP-3000 time clock

84 Rick Bruner Fri, Dec 17, 2010 How To's, Tricks, Tips 1 13971

What should I do if the clock display Err1?

Answer:

If you see "Err1" on the display of your CP-3000 the ink ribbon will need to be replaced as the imprint is too light for the sensor to read the printed blocks.

Online URL: http://tkb.amano.com/article.php?id=84