

## **PIX-3000 Printing all Zeros.**

87 [Alex Nieves](#) Wed, Dec 22, 2010 [FAQ's](#) 1 3703

**My PIX-3000 is printing all zeros, how do I resolve this issue?**

### **Answer:**

You need to reset the clock to factory default. To do this:

1. Hold down the **PROGRAM** button.
2. While continuing to hold the **PROGRAM** button, press the **RESET** button.
3. When the display flashes as shown, release the **PROGRAM** button.

4. Press the **RESET** button and the normal display will return.

5. Set the correct date and time.

*Note: This procedure will set the clock to factory default so any program, like custom print, will be erased.*

Online URL: <http://tkb.amano.com/article.php?id=87>