

How to disable day light savings on clock terminals

95 [Frank Mateo](#) Thu, Jan 20, 2011 [FPT-40/80 Fingerprint Terminal](#), [HandKey Terminals](#), [MTX-15 Terminal](#), [Time Guardian Version 4.0 or Lower](#) 0 16055

The below instructions applies to Time Guardian version 4 or lower versions on how to disable day light savings on the clock terminals:

1. Go to setup > wizard
2. terminal
3. Go to the DST or daily saving time section at the last bottom questions, set it to NO
4. Save
5. Click finish on the wizard

6. Then go to the communication menu and do a downloading

7. If that fails, autoupdate 1st then downloading

Online URL: <http://tkb.amano.com/article.php?id=95>