

TCX-11, TCX-21, and TCX-22 Time Clock Daylight Saving (DST) Instructions

106 [David Lopez](#) Wed, Mar 16, 2011 [How To's, Tricks, Tips](#) 3 4654



Introduction

This instruction sheet with embedded flash (flv format) videos details how to setup daylight saving start and end dates. Also included is how to adjust time/date values and get into these programming features.

Please view and/or download the attachment for complete instructions.

Note: the embedded Flash videos may require Adobe Flash player [or similar Flash player] and Adobe Reader version 9 or higher to play.

Conclusion

Thank you for your time, and have a great day. As always, feel free to submit ideas on topics you want addressed in the Amano Knowledge Base using the comments feature.

Amano Cincinnati, Inc. reserves the right to make equipment changes and improvements which may not be reflected in this article. Portions of this article may have been updated to include the latest hardware or firmware version, if applicable. Amano assumes no liability for errors and/or omissions. If you should find any errors or unclear information, please notify Amano by posting a comment.

Customer Support Information

Call toll-free in the U.S.: 800-253-9836 (outside U.S. call 973-364-0294) or Fax: 973-364-1091
Mailing address: Amano Cincinnati, Inc., 140 Harrison Ave., Roseland, New Jersey 07068
Web site: www.amano.com/time • E-mail: support@amano.com

Online URL: <http://tkb.amano.com/article.php?id=106>