MRX-35 ERROR 22

238 Alex Nieves Tue, Mar 15, 2011 FAQ's, How To's, Tricks, Tips 0 4033

AMANO.

Introduction

HOW TO CLEAR ERROR 22 ON THE MRX-35?

ANSWER:

ERROR 22 MEANS MEMORY IS FULL. THERE ARE 50 CARDS ALREADY ON MEMORY. TO

CLEAR OUT THE ERROR YOU NEED TO CLEAR THE MEMORY OR WAIT FOR NEXT PAY PERIOD.

HERE ARE THE STEPS FOR THE CLEAR...

FIG 1

- UNPLUG THE CLOCK.
- HOLD DOWN BUTTONS 2,3,4.
- APPLY POWER AND CONTINUE TO HOLD THE BUTTONS
   UNTIL DISPLAY SHOWS THE NUMBER 1. (see figure 1)

FIG 2

FIG 3

-PRESS BUTTON 4 UNTIL DISPLAY SHOWS 98. (see figure 2)
-PRESS BUTTON 6 AND CL SHOULD APPEAR. (see figure 3)
-PRESS BUTTON 6 AGAIN TO CONFIRM THE CLEAR.

- THE DISPLAY WILL SHOW A 1 AGAIN.
- PRESS BUTTON 4 UNTIL DISPLAY SHOWS 12.
- PRESS BUTTON 6 AND THE DISPLAY WILL RETURN
    TO NORMAL TIME.

NOTE: YOU WILL NEED TO REPROGRAM THE CLOCK
          BEFORE USE.

Conclusion

Thank you for your time, and have a great day. As always, feel free to submit ideas on topics you want addressed in the Amano Knowledge Base using the comments feature.

Amano Cincinnati, Inc. reserves the right to make equipment changes and improvements which may not be reflected in this article. Portions of this article may have been updated to include the latest hardware or firmware version, if applicable. Amano assumes no liability for errors and/or omissions. If you should find any errors or unclear information, please notify Amano by posting a comment.

Online URL: http://tkb.amano.com/article.php?id=238