

Factory Reset PIX-55

396 [Frank Mateo](#) Wed, Dec 7, 2011 [Time Clocks](#) 1 14885



Introduction

- Press **PROGRAM** for 2 seconds then release.
- Press **CHANGE** until "**Ot hr P5**" appears.
- Press **ENTER**
- Press **CHANGE** until "**diA9 18**" appears.
- Press **ENTER**
- Press **CHANGE** until "**clr d4**" appears.
- Press **ENTER**
- Press **CHANGE** until the right hand digit reads "**2**"
- Press **ENTER**
- Press **CHANGE** until the left hand digit reads "**3**"
- Press **ENTER 2 (two)** times.
- Press **PROGRAM** to exit.

Your Time Clock has now been reset to the factory default settings.

Conclusion

Thank you for your time, and have a great day. As always, feel free to submit ideas on topics you want addressed in the Amano Knowledge Base using the comments feature.

Amano Cincinnati, Inc. reserves the right to make equipment changes and improvements which may not be reflected in this article. Portions of this article may have been updated to include the latest hardware or firmware version, if applicable. Amano assumes no liability for errors and/or omissions. If you should find any errors or unclear information, please notify Amano by posting a comment.

Customer Support Information	Call toll-free in the U.S.: 800-253-9836 (outside U.S. call 973-364-0294) or Fax: 973-364-1091 Mailing address: Amano Cincinnati, Inc., 140 Harrison Ave., Roseland, New Jersey 07068 Web site: www.amano.com/time • E-mail: support@amano.com
---	---

Online URL: <http://tkb.amano.com/article.php?id=396>