

# HOW TO CONNECT FPT80 Network

513 [Frank Mateo](#) Wed, Aug 10, 2016 [FPT-40/80 Fingerprint Terminal](#), [Time Guardian Series \(TG 5.x, TG Plus 2.x, TG Pro 4.x\)](#) 1 7160

**AMANO.**

## Introduction

### HOW TO CONNECT FPT80 Network

1. retrieve IP from clock:
2. press MENU, COMM, NETWORK, DHCP = on, take note of IP address
- 3.
4. go to TG
5. LOCATION, open or add new location (+)
6. verify/setup with location name and clock type
7. enter IP in connection tab
8. add or edit terminal 0 for network clocks
9. save all settings

To check connection:

1. in TG, go to COMMUNICATIONS
2. highlight clock name
3. while looking at the clock display or have someone else look
4. in TG, press the green box with down arrow and circle (set time)
5. the display in the clock will also change

---

## Conclusion

Thank you for your time, and have a great day. As always, feel free to submit ideas on topics you want addressed in the Amano Knowledge Base using the comments feature.

Amano Cincinnati, Inc. reserves the right to make equipment changes and improvements which may not be reflected in this article. Portions of this article may have been updated to include the latest hardware or firmware version, if applicable. Amano assumes no liability for errors and/or omissions. If you should find any errors or unclear information, please notify Amano by posting a comment.

<b>Customer Support Information</b>	Call toll-free in the U.S.: 800-253-9836 (outside U.S. call 973-364-0294) or Fax: 973-364-1091 Mailing address: Amano Cincinnati, Inc., 140 Harrison Ave., Roseland, New Jersey 07068 Web site: <a href="http://www.amano.com/time">www.amano.com/time</a> • E-mail: <a href="mailto:support@amano.com">support@amano.com</a>
---	---

Online URL: <http://tkb.amano.com/article.php?id=513>