

PIX-3000 xNT Device Ethernet board connection

61 [Frank Mateo](#) Tue, Jan 4, 2011 [How To's, Tricks, Tips](#) 0 8390



Introduction

There are four areas involved in setting up the Ethernet board they are: Ethernet board, ARP (Address Resolution Protocol), Telnet (a text interface used to communicate to TCPIP devices) and finally assigning the IP address to a Location within TruTime. These steps are discussed in the attached document with additional information being provided when needed.

Note: Please see attachment.

Conclusion

Thank you for your time, and have a great day. As always, feel free to submit ideas on topics you want addressed in the Amano Knowledge Base using the comments feature.

Amano Cincinnati, Inc. reserves the right to make equipment changes and improvements which may not be reflected in this article. Portions of this article may have been updated to include the latest hardware or firmware version, if applicable. Amano assumes no liability for errors and/or omissions. If you should find any errors or unclear information, please notify Amano by posting a comment.

Customer Support Information	Call toll-free in the U.S.: 800-253-9836 (outside U.S. call 973-364-0294) or Fax: 973-364-1091 Mailing address: Amano Cincinnati, Inc., 140 Harrison Ave., Roseland, New Jersey 07068 Web site: www.amano.com/time • E-mail: support@amano.com
---	---

Online URL: <http://tkb.amano.com/article.php?id=61>