

# Why do the minutes keep flashing on the CP-3000

88 [Rui Pires](#) Wed, Dec 22, 2010 [FAQ's](#) 0 1753

**AMANO.**

## Introduction

**Why do the minutes keep flashing?**

### Answer:

The master/slave option is set to '1' in the program mode menu item 52. To stop the minutes from flashing, go into the program mode menu item #52 and set it to '0'.

---

## Conclusion

Thank you for your time, and have a great day. As always, feel free to submit ideas on topics you want addressed in the Amano Knowledge Base using the comments feature.

Amano Cincinnati, Inc. reserves the right to make equipment changes and improvements which may not be reflected in this article. Portions of this article may have been updated to include the latest hardware or firmware version, if applicable. Amano assumes no liability for errors and/or omissions. If you should find any errors or unclear information, please notify Amano by posting a comment.

**Customer  
Support  
Information**

Call toll-free in the U.S.: 800-253-9836 (outside U.S. call 973-364-0294) or Fax: 973-364-1091  
Mailing address: Amano Cincinnati, Inc., 140 Harrison Ave., Roseland, New Jersey 07068  
Web site: [www.amano.com/time](http://www.amano.com/time) • E-mail: [support@amano.com](mailto:support@amano.com)

Online URL: <http://tkb.amano.com/article.php?id=88>