

PIX-55 and TCX-45 Directions

dAtE P1 (04 10 07)

CLoc P2 (02 45 00^{am} pm)

dLSt P3 (on or off)

Prnt P4 (Print Settings)

Othr P5

Prnt 11 (Code Pr; SybL Pr) *enter*

Lang 12

Prdr 13 (right or left)

AP rt 14 (P on; OFF; P:5 on)

Zero 15 (OFF and on)



bdLt 16 (03 09 08)

EdLt 17 (11 04 07)

dIAg 18

Soft d1



Lcd d2 (tests display)

nPrnt d3

CLr d4 (00 – stays same; 32 – clears memory-)

Right to Left

** Will go back to Othr P5

