

Troubleshooting error messages E3 & E4 in model(s) PIX-10/15/21 & TCX-11/21/22

217 [Kathryn Smizer](#) Mon, Jan 23, 2012 [FAQ's](#), [FAQ's](#), [How To's](#), [Tricks, Tips](#), [How To's](#), [Tricks, Tips](#), [PIX-10/15/21](#) 32 195180

AMANO.

Introduction

Question: Troubleshooting error messages E3 & E4 in model(s) PIX-10/15/21 & TCX-11/21/22.

Answer: See attached document:

Conclusion

Thank you for your time, and have a great day. As always, feel free to submit ideas on topics you want addressed in the Amano Knowledge Base using the comments feature.

Amano Cincinnati, Inc. reserves the right to make equipment changes and improvements which may not be reflected in this article. Portions of this article may have been updated to include the latest hardware or firmware version, if applicable. Amano assumes no liability for errors and/or omissions. If you should find any errors or unclear information, please notify Amano by posting a comment.

**Customer
Support
Information**

Call toll-free in the U.S.: 800-253-9836 (outside U.S. call 973-364-0294) or Fax: 973-364-1091
Mailing address: Amano Cincinnati, Inc., 140 Harrison Ave., Roseland, New Jersey 07068
Web site: www.amano.com/time • E-mail: support@amano.com

Online URL: <http://tkb.amano.com/article.php?id=217>